



Crowcon Technical Note

Document Reference: GEN066 – PC Communications Accessories for Portables – Issue 2

Date: 11/06/2018

Document applies to: All Crowcon Portables

This document provides an overview of the communications hardware accessories required to enable communication with a PC. For communications software requirements, please refer to GEN065.

	 <p>Crowcon SGD Clip</p>
<p>Accessories Required</p>	 <p>CL-IR-LINK</p>




Crowcon Technical Note

	 <p>Gasman</p>
<p>Accessories Required</p>	<p>C01940, Single way charger/interface 12Vdc input C03580, Multi-region power supply E07532, PC lead (9 way D, female to female) C02097, USB to RS232 adaptor (if connecting to USB port)</p> 
<p>Accessories also available as a kit</p>	<p>C011305, Charger interface kit (includes all of the above)</p>


Crowcon Technical Note

	 <p>Tetra 3</p>
<p>Accessories Required</p>	<p>C011019, Single way charger/interface 12Vdc input C03580, Multi-region power supply E07532, PC lead (9 way D, female to female) C02097, USB to RS232 adaptor (if connecting to USB port)</p> <div style="display: flex; justify-content: space-around;">     </div>
<p>Accessories also available as a kit</p>	<p>C011306, Charger interface kit (includes all of the above)</p>



Crowcon Technical Note


	 Gas Pro,  T4
Accessories Required	Either of these: CH0103, USB communications lead (not powered) CH0104, USB dual communication and power lead (charges from USB port) 

Crowcon Technical Note

	 <p>Triple Plus +</p>												
<p>Accessories Required</p>	<p>Charger Interface for the appropriate region:</p> <table border="1" data-bbox="405 775 1326 1010"> <tr> <td>C01439</td> <td>Charger/Interface II for Australia only</td> </tr> <tr> <td>C01438</td> <td>Charger/Interface II for Europe only</td> </tr> <tr> <td>C01626</td> <td>Charger/Interface II for South Africa only</td> </tr> <tr> <td>C01436</td> <td>Charger/Interface II for UK only</td> </tr> <tr> <td>C01437</td> <td>Charger/Interface II for USA only</td> </tr> <tr> <td>C01440</td> <td>Charger/Interface II international without plug</td> </tr> </table> <p>C01327, Computer lead assembly 9 way to 9 way C02097, USB to RS232 adaptor (if connecting to USB port)</p> <div data-bbox="408 1214 1102 1368"> </div>	C01439	Charger/Interface II for Australia only	C01438	Charger/Interface II for Europe only	C01626	Charger/Interface II for South Africa only	C01436	Charger/Interface II for UK only	C01437	Charger/Interface II for USA only	C01440	Charger/Interface II international without plug
C01439	Charger/Interface II for Australia only												
C01438	Charger/Interface II for Europe only												
C01626	Charger/Interface II for South Africa only												
C01436	Charger/Interface II for UK only												
C01437	Charger/Interface II for USA only												
C01440	Charger/Interface II international without plug												

Crowcon Technical Note

	 <p>Detective +</p>
<p>Accessories Required</p>	<p>E07394, Computer lead assembly C02097, USB to RS232 adaptor (if connecting to USB port)</p> 

	 <p>Tetra</p>
<p>Accessories Required</p>	<p>E07985, IR adaptor for PC (plugs into RS232 port) C02097, USB to RS232 adaptor (if connecting to USB port)</p> 

For further information please contact us at customersupport@crowcon.com +44 (0)1235 557711